



The DB4 is the entry-level motor controller of the EXE line.

Description	Specification
Code	XC DB4
Number of channels	4
Control	Direct (400 – 415 V; 3 ph; 50 Hz)
Input power	Power cable with 1 x CEE 32A-5p plug
Output power	4 x CEE 16A 4p plug
Protection	<ul style="list-style-type: none"> <li>- Earth Break switch for power and control</li> <li>- Emergency STOP mushroom</li> <li>- Emergency Choke Coil</li> </ul>
Remote	No
Housing	19" 2U rack
Functional Description	<ol style="list-style-type: none"> <li>1 – Connect the 32A 3 phase plug to the power supply</li> <li>2 – Connect plugs to for the electric hoists concerned, to the appropriate sockets of the 16A 3 phase 4p</li> <li>3 – Check that emergency STOP mushroom is not engaged</li> <li>4 – Arm the Emergency Choke Coil</li> <li>5 – Arm the Magneto Thermal switch</li> <li>6 – Check that all 3 warning lights are illuminated</li> <li>7 – Engage the gear lever corresponding to each motor, to the position required: UP, lever in left position, DOWN, lever in right position.</li> <li>8 - Pushing the GO button will activate the motors to move simultaneously</li> <li>9 – Releasing the GO button will cease the movement of the motors, simultaneously</li> </ol>
Date of issue 16/03/2005	LITEC s.r.l. – Via Venier, 52 – 30020 Marcon (VE) www.litectruss.com - info@litectruss.com
	LLTCST72GB1 Version 2